

# Solco XL Jointing / Reinforcing Tape

## Solco XL Jointing / Reinforcing Tape:

### Description:

Solco XL Reinforcement Jointing Tape is a single sided reinforcing / over-banding tape used for securing Solco Gas & Waterproofing Membranes at overlaps edge and corner details. Solco XL Tape is a 1.5mm thick preformed bitumen compound that is laminated onto an impervious, non-perforated, cross laminated HDPE film. The tape is protected on the self-adhesive side with a silicone coated release film. Solco XL Jointing Tape conforms to the requirements of BS 8102 as part of the Solco Gas & Waterproofing Systems. Substrates should be primed with Solseal HP Bitumen Emulsion / Primer prior to application.

### Application:

A single sided reinforcing / over-banding tape for securing waterproofing membranes at overlaps edge and corner details.

### Installation:

- Ensure that surfaces are clean and dry.
- Apply tape equidistant over the bonded membrane lap. Apply pressure to the tape to ensure adhesion.
- When the weather is cold, store tape in a warm, dry place until required.
- Installation is not recommended below 5°C.



## Solco XL Gas Resistant Jointing / Reinforcing Tape:

### Description:

Solco XL Gas Resistant Jointing Tape is a preformed bitumen compound with resistance to Methane, Radon and Carbon Dioxide. Resistance to gas is achieved with a high density polyethylene film (PE) reinforcement bonded to 50-micra aluminium foil, an easily removable silicone film on the underside, and thermofusible film on the upper side.

Solco XL Gas Resistant Jointing Tape conforms to the requirements of BS8485:2015+A1:2019 as part of the Gas Protection System.

Substrates should be primed with Solseal Bitumen Primer prior to application.

Solco XL Gas Resistant Jointing Tape can be used with Solcourse range of GR DPC's and other Solshield Gas Membranes.

### Application:

A single sided reinforcing / over-banding tape for securing waterproofing and gas proofing membranes at overlaps edge and corner details.

### Installation:

- Ensure that surfaces are clean and dry.
- Apply tape equidistant over the bonded membrane lap. Apply pressure to the tape to ensure adhesion.
- When the weather is cold, store tape in a warm, dry place until required.
- Installation is not recommended below 5°C.



| Property    | Value                 |
|-------------|-----------------------|
| Thickness   | 1.5mm                 |
| Width       | 100mm / 150mm / 300mm |
| Length      | 20m                   |
| Roll Weight | 3 kg / 4.5 kg / 9 kg  |
| Colour      | Black                 |

Solco, Unit 51, Portmanmoor Road Industrial Estate, Ocean Park, Cardiff, CF24 5HB